SmallRig

**SR-RG1**

Wireless Shooting Grip—User Manual

Foreword

Thank you for purchasing SmallRig's product.

Warnings

• Please read this User Manual carefully.
• Please do not use the product in water.
• The product contain electronic components, do not let the product fall to the ground, be hit, or suffer a violent impact.
• Please do not use the product in a completely closed environment. It may increase the internal temperature of the product, which causes product failure, ignition, or other accident.
• Never remove the non-detachable lithium battery in the product without permission.
• When the battery of the product is not in use for a long time, please charge and discharge the battery every six months, and provide it with about 60% of the electric quantity to prolong its service life.
• Since there are some hazardous substances in the battery of the product, please do not discard it. Instead, dispose of the product that is damaged or will never be used according to the waste management measures.
• When the product is not in use, it should be stored in a dry and clean place. Avoid high temperature, high humidity, and strong magnetic field.
• Do not ingest battery, Chemical Burn Hazard；This product contains a button cell battery. If the button cell battery is swallowed, it can cause severe internal burns in just 2 hours andcan lead to death.
• Keep new and used batteries away from children.
• If the battery compartment does not close securely, stop using the product and keep it away from children.
• If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

⚠ Please do not disassemble the product. If you have any questions, please contact the seller to apply for after-sales service.

In the Box

1. Wireless Shooting Grip   × 1
2. USB-A to USB-C Cable   × 1
3. User Manual   × 1

Compatibility

 ZV–1 / ZV–E10 / RX100 VII / RX0 II / Alpha 6100 / Alpha 6400 / Alpha 6600 / Alpha 7C / Alpha 7 III / Alpha 7R III / Alpha 7R IV / Alpha 7S III / Alpha 7 IV / Alpha 9 / Alpha 9 II

EOS M6 Mark II / EOS M50 / EOS M50 II / EOS M200 / EOS R / EOS R5 / EOS R6 / EOS R7 / EOS R10 / PowerShot G5X II / G7X III

Identifying the parts

1. 1/4" Camera Screw
2. Rotate Button
3. Tilt Button
4. Battery Level and Charging Indicator
5. BLE Indicator
6. TW: Zoom Button
7. FOCUS / PHOTO Button
8. REC Button
9. ON / OFF Button
10. C1 Button
11. Charging Port

* FOCUS / PHOTO button: Half press to focus, fully press to take photo.

Features

360°

180°

* Please do not use the grip as tripod when extended.

Pairing

1. Turn on the remote control.
2. Set the camera drive mode to 【Remote】 or 【Self-timer:10 sec / remote or 2 sec remote】.
3. Select MENU—Network—【BLE Settings】 — 【BLE】 — 【Enable】.
4. Select MENU—Network—【BLE connection】 — 【Connect to Wireless Remote】 — 【Add a device to connect to】.
5. Press the REC button and C1 button until the indicator light on the right side flashes stably.
6. When a confirmation message "Paired with SR-RG1"appears on the camera's screen, select 【OK】.

Canon Camera

1. Turn on the remote control.
2. Pairing the unit with the mounted camera.
   Select MENU—Network— 【BLE Settings】 — 【BLE Function】 — 【On】.
   Select MENU—Network— 【BLE Rmt Ctrl】 — 【On】.
   Select MENU—Network— 【BLE Settings】 — 【Pairing】.
3. Press the REC button and C1 button until the indicator light on the right side flashes stably.
4. When a confirmation message SR-RG1 appears on the camera's screen, select 【OK】.
5. When pairing is complete, 【Paired】 appears, select 【OK】.

* Depending on the camera, the setup method for remote control shooting may differ, please refer to the instruction manual for your camera.

Indicator Light

1. Left Indicator
- flicker four bars at battery level of 75% ~ 100%
- flicker three bars at battery level of 50% ~ 75%
- flicker two bars at battery level of 25% ~ 50%
- flicker one bars at battery level of 1% ~ 25%

2. Right Indicator
   Constant lighting means BLE is connected successfully, while flickering means BLE is not connected.

Product Specification

Remote Range:	10m / 32.8ft
Load Capacity (Folded):	1.5kg
Load Capacity (Extended):	0.5kg
Battery Capacity:	3.7V / 200mAh / 0.74Wh
Charging Input:	5V⎓1A
Net Weight:	210 ± 5g
Product Dimensions:	174,8 × 46 × 39.4mm

Service Warranty

Please keep your original receipt and guarantee card. Be sure the dealer has written on it the date of purchase and SN of the product. These are required for warranty service.

After-sale Warranty Terms

SmallRig products are entitled to warranty services as of the date of payment.
• Electronic products（except V mount battery): 1-year warranty.
• V mount battery: 2-year warranty.
• Non-electronic products: 2-year warranty.

This Warranty Does Not Cover

1. If users fail to adhere to the "Operating Instruction" or any "Warnings" stated in the user manual, resulting in a quality failure, it falls outside the scope of warranty coverage.
2. The product identification or SN label is removed or defaced in any way.
3. Product damage caused by problems not attributable to the quality of the products such as improper use of the products.
4. Product damage caused by unauthorized modification, disassembly, repair and other acts.
5. Product damage caused by fires, floods, lightning and other force majeure factors.

Warranty Mode

• For the products within the scope of warranty, SmallRig will repair or replace them on the basis of specific failures; the repaired / replaced products / parts are entitled to the remaining part of the original warranty period.

Contact Information

• You're advised to contact the online customer service personnel of corresponding shopping platform and submit a repair service application.
• You may also apply for repair service through SmallRig's service email.
Service Email: support@smallrig.com

Guarantee Card

ID No.	
Item Name	
Purchase Date	
User Name	
Mobile	
Address	
Receipt	

WE ARE HERE FOR YOU
服务与支持

ETICHETTATURA AMBIENTALE
ENVIRONMENTAL LABELING

EC	REP	Prolinx GmbH Brehmstr.56,40239 Duesseldorf Germany eu@eulinx.eu
UK	REP	Prolinx Global LTD 27 Old Gloucester Street London,WC1N3AX, UK eu@eulinx.eu

Manufacturer: Shenzhen Leqi Innovation Co., Ltd.
Add: Rooms 103, 501 and 601, Building 5, Fenghe Industrial Park,
    Nos. 1301-50 Guanguang Road, Longhua District, Shenzhen,
   Guangdong, China.

Consignor: Shenzhen LC Co., Ltd.
Add: Rooms 602, Building 5, Fenghe Industrial Park, No. 1301-50
    Guanguang Road, Xinlan Community, Guanlan Street, Longhua
    District, Shenzhen, Guangdong, China.

$C \in \widehat{C}$ **RoHS** ♻ 🚫 合格证
已检验

FCC ID: 2AZWI-3326LEQI
IC: 27649-3326LEQI

Ⓡ 210-174005

22
PAP

Made in China

SmallRig

SR-RG1

多功能无线拍摄手柄–用户手册

前言

感谢您购买SmallRig产品。

重要提示

· 请认真阅读用户手册。

· 请勿在水中使用本产品。

· 本产品内部含有电子元件, 需注意不要高处跌落或强烈撞击。

· 请勿在完全封闭的环境下使用, 否则可能使产品内部温度升高而导致产品故障、起火或发生意外事故。

· 本产品含有内置式不可拆卸锂电池, 严禁擅自拆机。

· 本产品在长时间储存不用时, 应在6个月内进行一次充放电维护, 并恢复60%左右的带电量, 以延长电池的使用寿命。

· 本产品内部有少许有害物质, 请勿任意丢弃, 请将损坏或是不再使用的产品, 依废废弃物管理办法回收处理。

· 本产品不用时, 应将其存放在干燥清洁处, 避免高温、高湿及强磁场的场所存放或使用。

· 请勿吞食电池, 有化学烧伤风险。本产品含有纽扣电池。如果吞食纽扣电池, 2小时内就会造成严重的内部烧伤, 并可能导致死亡。

· 请将新电池和旧电池放在远离儿童的地方。

· 如果电池盒盖无法牢固关闭, 请停止使用产品并让产品远离儿童。

· 如果您认为电池可能被吞食或放置在身体的任何部位, 请立即就医。

⚠️ **请勿拆卸产品或更换电池, 如您怀疑产品有任何问题, 请联系购买平台, 申请售后处理。**

包装清单

1. 手柄　　　　　　　　　　　×1
2. USB-A 转 USB-C 数据线　×1
3. 用户手册　　　　　　　　　×1

适配性

 ZV-1 / ZV–E10 / RX100 VII / RX0 II / Alpha 6100 / Alpha 6400 / Alpha 6600 / Alpha 7C / Alpha 7 III / Alpha 7R III / Alpha 7R IV / Alpha 7S III / Alpha 7 IV / Alpha 9 / Alpha 9 II

EOS M6 Mark II / EOS M50 / EOS M50 II / EOS M200 / EOS R / EOS R5 / EOS R6 / EOS R7 / EOS R10 / PowerShot G5X II / G7X III

按键说明

1、¼"锁紧螺丝

2、水平旋转按钮

3、仰俯调节按钮

4、电量及充电指示灯

5、BLE连接指示灯

6、TW: 变焦推杆按钮

7、对焦 / 拍照按钮

8、录像按钮

9、开 / 关按钮

10、C1: 自定义按钮

11、充电接口

* 对焦拍照按钮为双段开关，轻按对焦，重按拍照

## 产品特点

水平 360° / 仰俯 180°

360°

180°

可拉伸15cm

可拆卸无线遥控器

三脚架功能

*请勿在拉伸状态下使用三脚架功能，避免设备跌落，损坏相机。

配对方式

1、将遥控器开关调至打开（ON）位置；

2、选择相机BLE设置

　　选择MENU — 网络 —【BLE设置】—【BLE功能】—【开】；

　　选择MENU — 网络 —【BLE遥控】—【开】；

　　选择MENU — 网络 —【BLE设置】—【配对】；

3、长按遥控器C1按钮+录像按钮直至指示灯快闪后松手，右侧指示灯常亮；

4、相机屏幕显示已连接装置：SR-RG1，选择【确定】；

5、屏幕显示【已配对】，再次点击【确定】即完成配对；

1、将遥控器开关调至打开（ON）位置；

2、将相机驱动模式设为【遥控】或【自拍：10秒/遥控】；

3、选择MENU — 网络 —【BLE设置】—【BLE】—【启用】；

4、选择MENU — 网络 —【BLE连接】—【连接至无线遥控器】—
　　【添加要连接的设备】；

5、长按遥控器C1按钮+录像按钮直至指示灯快闪后松手，右侧指示灯常亮；

6、相机屏幕显示已与SR-RG1配对，选择【确定】；

*遥控拍摄的设置方法可能随相机不同而变化，详细信息请参阅
相机使用说明书中遥控相关章节。

指示灯说明

　1、左指示灯

　• 闪烁4次，电量代表75%～100%；

　• 闪烁3次，电量代表50%～75%；

　• 闪烁2次，电量代表25%～50%；

　• 闪烁1次，电量代表1%～25%；

2、右指示灯

　BLE指示：常亮代表BLE配对成功，闪烁代表BLE配对失败。

产品规格

遥控距离：	10米
最大承重(拉伸前)：	1.5kg
最大承重(拉伸后)：	0.5kg
电池容量：	3.7V / 200mAh / 0.74Wh
充电输入：	5V⎓1A
产品净重：	210 ± 5g
产品尺寸：	174.8 × 46 x 39.4mm

保修条款

请保留您的原始购买单据及保修卡，同时包含您的购买日期、产品序列号等，这些资料质保服务时均需要提供。

售后质保条款

SmallRig产品自下单付款之日起享有质保服务。

·电子产品(除V口电池): 1年质保。

·V口电池：2年质保。

·非电子产品：2年质保。

注：若销售地国家或地区的适用法律法规有冲突的，以销售地国家或地区有关质保期的法律法规为准。

质保无效说明

1. 当用户违反操作指引或用户手册中"重要提示"任何一条导致的质量失效，不在质保范围内。

2. 产品序列号标识已经被撕毁或无法辨识，不在质保范围。

3. 产品使用不当等非产品本身质量问题，而造成的产品损坏，不在质保范围。

4. 非官方指导的私自改装、拆解、维修等行为而造成的损坏，不在质保范围。

5. 因火灾、水灾、雷击等不可抗拒力造成的产品损坏，不在质保范围。

维修方式

• 属于质保范围的，SmallRig 根据产品具体的故障对产品进行维修或更换；维修后的产品 / 部件享受原有保修期的剩余时长。

联系方式

• 建议您优先前往相应购买平台联系在线客服，提出产品维修申请。

• 您也可以通过 SmallRig 服务邮箱申请维修服务。

服务邮箱：support@smallrig.com

保修卡

ID编号	
产品名称	
购买日期	
用户姓名	
用户电话	
用户地址	
购买单据	

制造商: 深圳市乐其创新股份有限公司

地址: 中国广东省深圳市龙华区观澜街道新澜社区观光路 1301-50 号
丰和工业园厂房 5 栋 103、501、601

委托商: 深圳市乐长科技有限公司

地址: 中国广东省深圳市龙华区观澜街道新澜社区观光路 1301-50 号
丰和工业园厂房 5 栋 602

LQ-P1335-18   执行标准: GB 4943.1-2011

C E ◎ RoHS ♻ 合格证 已检验

F© FCC ID: 2AZWI-3326LEQI
IC: 27649-3326LEQI   ℝ 210-174005

PAP 22

中国制造