

SmallRig

DT-E6P Power Cable (For Canon LP-E6P)

Operating Instruction

Thank you for choosing SmallRig products.

Important Reminder

- Please keep the product dry and avoid contact with water or other liquids.
- Do not use the product in high temperature, humid, or dusty environments.
- Keep the product away from flammable materials and avoid prolonged use.
- If any damage is found on the product, please stop using it immediately and contact the after-sales service department for repair or replacement.

In the Box

DT-E6P Power Cable	× 1
Operating Instruction	× 1

Specifications

Items	Parameters
Output Voltage (Max)	8.5V
Output Voltage (Min)	7.8V
Output Current (Max)	6A
Output Protection Current	6.5 - 7.5A
D-Tap Input Voltage	9.5 - 20V
D-Tap Input Current (Max)	3.5A
Operating Temperature	0°C to 45°C / 32°F to 113°F
Storage Temperature	-20°C to 60°C / -4°F to 140°F
Material(s)	ABS + PC + PVC
Input Specifications	Male D-Tap connector, spring wire stretching to 2.0m ± 50.0mm / 78.7 ± 2.0in

* The data are measured by SmallRig Lab but may vary based on specific circumstances.

How to use

1. Connect the dummy battery to the power source.
2. Properly install the dummy battery in the camera battery compartment.
3. Close the battery compartment cover.

Service & Warranty

Please keep your original receipt and guarantee card. Be sure the dealer has written on it the date of purchase and SN of the product. These are required for warranty service.

After-sale Warranty Terms

SmallRig products are entitled to warranty services as of the date of payment.

- Electronic products (except V mount battery): 1-year warranty.
- V mount battery: 2-year warranty.
- Non-electronic products: 2-year warranty.

Note: In case of any conflict between our warranty period policy and applicable laws and regulations of the country / region where the products are sold, the latter shall prevail.

This Warranty Does Not Cover

1. If users fail to adhere to the "Operating Instruction" or any "Warnings" stated in the user manual, resulting in a quality failure, it falls outside the scope of warranty coverage.
2. The product identification or SN label is removed or defaced in any way.
3. Product damage caused by problems not attributable to the quality of the products such as improper use of the products.
4. Product damage caused by unauthorized modification, disassembly, repair and other acts.
5. Product damage caused by fires, floods, lightning and other force majeure factors.

Warranty Mode

• For the products within the scope of warranty, SmallRig will repair or replace them on the basis of specific failures; the repaired / replaced products / parts are entitled to the remaining part of the original warranty period.

Contact Information

- You're advised to contact the online customer service personnel of corresponding shopping platform and submit a repair service application.
- You may also apply for repair service through SmallRig's service email.
Service Email: support@smallrig.com

Guarantee Card

ID No.	
Item Name	
Purchase Date	
User Name	
Mobile	
Address	
Receipt	

Manufacturer Email: support@smallrig.com

Manufacturer: Shenzhen Leqi Innovation Co., Ltd.

Add: Rooms 101, 701, 901, Building 4, Gonglianfuji Innovation Park,
No. 58, Ping'an Road, Dafu Community, Guanlan Street,
Longhua District, Shenzhen, Guangdong, China.

Consignor: Shenzhen LC Co., Ltd.

Add: Room 201, Building 4, Gonglianfuji Innovation Park, No. 58,
Ping'an Road, Dafu Community, Guanlan Street, Longhua
District, Shenzhen, Guangdong, China.



GAVIMOSA CONSULTORIA, SOCIEDAD LIMITADA,
CASTELLANA 9144, 28046 Madrid,
compliance.gavimosa@outlook.com



Sea&Mew Accounting Ltd,
Electric Avenue Vision 25, London, Enfield EN3 7GD,
info@seamew.net

CE RoHS



Séparez les éléments avant de trier



Made in China

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

SmallRig

DT-E6P 电源线 (适用于佳能 LP-E6P)

操作指引

感谢您购买 SmallRig 产品。

重要提示

- 请保持产品干燥，避免接触水或其他液体。
- 请勿在高温、潮湿或多尘的环境中使用产品。
- 请勿将产品置于易燃物品附近，并避免长时间使用。
- 若发现产品有任何损坏，请立即停止使用并联系售后服务部门进行维修或更换。

包装清单

DT-E6P 电源线	× 1
操作指引	× 1

规格参数

项目	规格
输出最大电压	8.5V
输出最小电压	7.8V
最大输出电流	6A
输出保护电流	6.5 - 7.5A
D-Tap输入电压	9.5 - 20V
D-Tap输入最大电流	3.5A
工作温度	0°C ~ 45°C
储存温度	-20°C ~ 60°C
材料	ABS + PC + PVC
输入规格	D-Tap 公头、弹簧线拉伸 2.0m ± 50.0mm

* 数据由 SmallRig 实验室测定值，但因客观环境改变，数据略有偏差。

使用方式

1. 假电池与电源连接。
2. 将已通电的假电池正确装入相机电池舱。
3. 关闭电池舱盖。

保修条款

请保留您的原始购买单据及保修卡,同时包含您的购买日期、产品序列号等,这些资料质保服务时均需要提供。

售后质保条款

SmallRig产品自下单付款之日起享有质保服务。

- 电子产品(除V口电池): 1年质保。
- V口电池: 2年质保。
- 非电子产品: 2年质保。

注:若销售地国家或地区的适用法律法规有冲突的,以销售地国家或地区有关质保期的法律法规为准。

质保无效说明

1. 当用户违反操作指引或用户手册中“重要提示”任何一条导致的质量失效,不在质保范围内。
2. 产品序列号标识已经被撕毁或无法辨识,不在质保范围。
3. 产品使用不当等非产品本身质量问题,而造成的产品损坏,不在质保范围。
4. 非官方指导的私自改装、拆解、维修等行为而造成的损坏,不在质保范围。
5. 因火灾、水灾、雷击等不可抗力造成的产品损坏,不在质保范围。

维修方式

- 属于质保范围的, SmallRig 根据产品具体的故障对产品进行维修或更换;
维修后的产品 / 部件享受原有保修期的剩余时长。

联系方式

- 建议您优先进往相应购买平台联系在线客服, 提出产品维修申请。
- 您也可以通过 SmallRig 服务邮箱申请维修服务。

服务邮箱: support@smallrig.com

保修卡

ID编号	
产品名称	
购买日期	
用户姓名	
用户电话	
用户地址	
购买单据	

制造商: 深圳市乐其创新股份有限公司

地址: 中国广东省深圳市龙华区观澜街道大富社区平安路58号
共联富基创新园4栋101、701、901

委托商: 深圳市乐长科技有限公司

地址: 中国广东省深圳市龙华区观澜街道大富社区平安路58号
共联富基创新园4栋201

执行标准: GB 4943.1-2022

LQ-B732-18

CE RoHS



合格证
已检验

中国制造